



Ideal Distributors

Tel: 03 95629899

Fax: 03 95629877

Email: sales@ideal-diy-floors.com.au

GOSH

Garage - Office - Shop - Home

INSTALLATION GRID FIX WITH PRESSURE SENSITIVE ADHESIVE

ADHESIVE LEVEL OPTIONS

 = A  = B

----- = Chalk lines

> FOR **LIGHT - MEDIUM** TRAFFIC REFER TO **A** LEVEL OF ADHESIVE USAGE.

> FOR **HEAVY** TRAFFIC REFER TO **A + B** LEVEL OF ADHESIVE USAGE.

- 1) Plan the positioning for the tiles by marking the floor with chalk lines for the joins.
- 2) Use a 20cm wide 6mm Nap Hair paint roller to apply the Pressure Sensitive (PS) Adhesive to the subfloor along the chalk lines.
- 3) Apply PS Adhesive so all 4 sides of the tiles are held.
- 4) PS Adhesive will take about 20 minutes to be ready to then lay the tiles.
- 5) When applied with a paint roller 1lt of PS Adhesive covers approx 6m²

